

## Series 9000

### Replacing the Hose

1. Wind spool flange clockwise -- facing swivel -- until spring is tight.
2. Back off three turns and latch.
3. Insert hose through roller guide.
4. Connect hose fitting to female outlet ell.

### Adjustments

To adjust spring tension, add or remove wraps of hose from the spool, one wrap at a time until desired tension obtained.

Reel w/hose	Reel w/o hose	Hose I.D.		Hose Length		# Wraps
D9275 OLPBW	D9200 OLPBW	1/2"	13mm	75'	23m	23
D9299 OLPBW	D9200 OLPBW	1/2"	13mm	100'	31m	21
D9350 OLPBW	D9300 OLPBW	3/4"	19mm	50'	15m	21
D9375 OLPBW	D9300 OLPBW	3/4"	19mm	75'	23m	21
D9399 OLPBW	D9305 OLPBW	3/4"	19mm	100'	31m	23
D9450 OLPBW	D9400 OLPBW	1"	25mm	50'	15m	21
Not Available	FF9500 OLPBW	1 1/4"	32mm	50'	15m	21
Not Available	FF9600 OLPBW	1 1/2"	38mm	50'	15m	21
D9275 OMP	D9200 OMPBW	1/2"	13mm	75'	23m	21
D9350 OMP	D9300 OMPBW	3/4"	19mm	50'	15m	21
D9175 OHP	D9100 OHPBW	3/8"	10mm	75'	23m	21