

Series 9000

Replacing the Hose

1. Wind spool flange clockwise -- facing swivel -- until spring is tight.
2. Back off three turns and latch.
3. Insert hose through roller guide.
4. Connect hose fitting to female outlet ell.

Adjustments

To adjust spring tension, add or remove wraps of hose from the spool, one wrap at a time until desired tension obtained.

Reel w/hose	Reel w/o hose	Hose I.D.		Hose Length		# Wraps
D9275 OLPBW	D9200 OLPBW	1/2"	13mm	75'	23m	23
D9299 OLPBW	D9200 OLPBW	1/2"	13mm	100'	31m	21
D9350 OLPBW	D9300 OLPBW	3/4"	19mm	50'	15m	21
D9375 OLPBW	D9300 OLPBW	3/4"	19mm	75'	23m	21
D9399 OLPBW	D9305 OLPBW	3/4"	19mm	100'	31m	23
D9450 OLPBW	D9400 OLPBW	1"	25mm	50'	15m	21
Not Available	FF9500 OLPBW	1 1/4"	32mm	50'	15m	21
Not Available	FF9600 OLPBW	1 1/2"	38mm	50'	15m	21
D9275 OMP	D9200 OMPBW	1/2"	13mm	75'	23m	21
D9350 OMP	D9300 OMPBW	3/4"	19mm	50'	15m	21
D9175 OHP	D9100 OHPBW	3/8"	10mm	75'	23m	21