

# Tech Bulletin

## 600869 Push Button Switch Installation Instructions

---

**Application:** The **600869** Switch Box performs the Power On/Off switching function to the reel motor. The 600869 is used for 12 Volt or 24 Volt applications and contains the required Power Relay and a 40 Amp Circuit Breaker.

---

**Mounting:** Remove the nuts from the mounting studs and use these nuts, with 1/4" lockwashers, to secure the box to your mounting site.

---


### Wiring Instructions:

On/Off Push Pushbutton

Circuit Breaker

Red


To (+) Pos. Battery Terminal



**NOTE:** If the Motor does not rotate in the desired direction, reverse the Motor Wires connected to the White Wire and the Neg Battery Terminal.

White  
To Motor Wire

Motor Wire  
To (-) Neg Battery Terminal



Form # TB0044 Rev: 5/2017